Data Sheet – BASgatewaySX



BASgatewaySX — Modbus to BACnet[®] Gateway with SSL

The BASgatewaySX makes Modbus device commissioning fast and easy thanks to pre-built device profiles and virtual routing. Modbus remains a popular network interface, and is commonly found on jobs such as boiler control, variable speed drives, and metering applications, but these devices lack BACnet compliance. To make Modbus devices appear as individual BACnet devices, a BASgatewaySX is used. The BASgatewaySX has one 10/100 Mbps Ethernet port for Modbus TCP and BACnet/IP and an opto-isolated Modbus EIA-485 serial port for Modbus RTU or Modbus ASCII devices. Up to 200 Modbus serial devices represented by up to 2,000 polled points can share the single Modbus EIA-485 port on the BASgatewaySX. BACnet COV notification is supported on 200 points (100 Analog and 100 Binary points). The virtual routing feature in the BASgatewaySX allows each connected Modbus device to appear as an individual BACnet compliant device. A device profile is needed for each Modbus type device. Contemporary Controls maintains a library of freelyavailable device profiles available for download at www.ccontrols.com/profiles.

Gateway Functionality Between ...

- Modbus Serial (RTU or ASCII) and BACnet/IP
- Modbus TCP and BACnet/IP

Routing Functionality Between...

• Modbus Serial (RTU and ASCII) and Modbus TCP

Flexible Communication Ports

- 10/100 Mbps Ethernet with auto-negotiation and Auto-MDIX
- Modbus EIA-485 port can support up to 200 Modbus serial devices (up to 2,000 polled points)
- Opto-isolated serial port supports either 2-wire or 3-wire EIA-485
- EIA-485 bias and termination DIP switches
- Baud rates from 2.4–115.2 kbps

CONTEMPORARY ONTROLS

If the device profile is not available, Contemporary Controls will provide it upon request. Custom Modbus device profiles can also be uploaded to the BASgatewaySX using the web page.

Using HTTPS web pages and a resident database of common Modbus device profiles, Modbus data points from Modbus Serial or Modbus TCP devices can be mapped to BACnet objects.



Convenient Installation

- 24 VAC/VDC powered
- DIN-rail mount (BASGSX-M1) or panel mount (BASGSX-M1/P)

Fast & Easy Modbus Commissioning

- More than 200 field-proven, pre-built Modbus device profiles available for free download
- Custom device profiles also be uploaded to the BASgatewaySX using its web page
- If you don't see your required Modbus device profile, we will gladly create it for you

BASgatewaySX — Modbus to BACnet Gateway with SSL

The BASgatewaySX is housed in a metal case that mounts on 35-mm DIN-rail, or panel mounts, depending on the option chosen, and it is powered from a 24 VAC/ VDC (\pm 10%) source. Its half-wave rectified power supply allows sharing of power with other half-wave devices.

The optically-isolated serial port allows for connection to either 2-wire or 3-wire EIA-485 networks using a removable 5-pin terminal block. Up to 200 EIA-485 Modbus serial devices represented by up to 2,000 polled points can share the serial bus at data rates between 2.4 and 115.2 kbps. External DIP switches allow flexible bias and termination options. They can be removed for mid-span installations.

The Ethernet port offers a shielded RJ-45 connector. Through auto-negotiation and Auto-MDIX, it automatically matches connections to the attached equipment. Therefore, either CAT5 straight-through or crossover cable can be used to attach to the BACnet/IP or Modbus TCP network at either 10 or 100 Mbps speed.

A resident web server allows for configuration, device status, and Modbus Utility operations using any standard web browser. HTTPS webpages allow cross-platform compatibility and browser support. A push button at the front is provided to return the unit to the factory default IP address of 192.168.92.68 /24 and credentials of: username: *admin* and password: *admin*. LED indicators provide communication status on both the Ethernet and serial ports.





Web Page Configuration

	CONTEMPORA						
<section-header><image/></section-header>	Home	Configure	Status Ma	pping Configuration	Modbus Utility	Upload	Logout
Configure Settings System System Marrie: ASgutewaySX PAddess: 192.168.268 Database 0.0.0 BACM CatewayAddess: Database Cate				X		Use this page to System, Modbus settings. System Mame: as you wish. IP Address: Ch yalue of 192.164 recommended. Subnet Mask: T 255.255.255.01	configure the s and BACnet Name your system anging the default .92.68 is
System System Name: ASgutewnySX Padees: System Name: 192.168.92.68 Statubul Name: System Name: 192.168.92.68 Statubul Name: System Name: 192.168.92.68 Statubul Name: System Name: System Name: 192.168.92.68 Statubul Name: System Name: <t< td=""><td>/ Configure Setti</td><td>ings</td><td></td><td></td><td></td><td>Gateway Addre</td><td></td></t<>	/ Configure Setti	ings				Gateway Addre	
System Name: BASquetowqSX PAdress: 1921080208 Stadent Max: 255:256.256.0 ↓ Genewoy Address: 0.0.0.0 BACNEL Device Instance: 255:900 (0 - 4194302) UDP Port: The default of 0.0-BAC0 BMD IP Address: 0.0.0 BMD IP Address: 0		ings		each screen i informatio	ncludes n that	enter its address BACnet Device Instance value (0-419430	: here. : Enter a unique 2) for the
µi Adates: 102. Ubs 20.2 88 Subore Masi: 255. 255. 255. 0 v 36. 0.0.0 BACnet Device Instance: 2459 9900 0 0 - 4184302 UP Per: 0.08.AC0 Protect Instance: 2459 9900 0 0 - 4184302 UP Per: 0.08.AC0 100 0 0 - 4184302 (readecimal value e.g. 0.8.A.C0) Fromfigure Settings Sets Vinual Network: 100 0 (100 - 3000 (100 - 3000 msec) Command Timeout (100 - 3000 msec) Correcting Dovice Instance: 2000 0 - 40.000 msec) Correcting Dovice Instance: 2000 0 - 40.000 msec) Correcting Dovice Instance: 1000 (100 - 30.000 msec) Correcting Dovice Instance: 2000 0 - 1000 msec) Correcting Dovice Instance: 2000 0 - 2000 0 - 2000 msec) Correcting Dovice Instance: 2000 D - 2000 0 - 2000 msec) 2000 0 - 2000 0 - 2000 msec) Correcting Dovice Instance: 2000 0 - 2000 msec) 2000 0 - 2000 0 - 2000 msec) 2000 0 - 2000 msec)	System Name:	BASgatewaySX			current	UDP Port: The	default of 0xBAC0
suber has no BBMD and the BAS no BBMD and the B				view		not be changed.	
BACnet Backet BBM PeqTime: 100 BBM PeqTime: 100 BBM PeqTime: 100 BBM PeqTime: 100 BBM PeqTime: 100 BBM PeqTime: 100 Baddraes: 0.0.0 BBM PeqTime: 100 Consecutive RabeLeD ▼ Modus: Baddraes: 19200 ▼ Protoci: Modus:RTU × Protoci: Protoci: Protoci: Protoci: Protoci: Protoci:				_		subnet has no B	BMD and the
BACnet Derive Instance: 2459900 (0 - 4194302) DP Port: 0xBACO (Fiexadecinal value e.g. 0xBACI) BBMD PG Time: 100 (1 - 65531) BBMD PG Time: 100 (1 - 65531) And Irelevant parameters (system + each protocol) Baudrate: 19200 ∨ Protocol: Modus RTU ∨ Parity: [100 (100 - 3000 msec) Offine Poll Pendt InterScan Delay: 2000 (100 - 60,000 msec) Delati = EVCH Nobetar Estan Delay Delati = EVCH Nobetar Estan Delati Delati Estan Delati Delati Estan Delati Delati Estan Delat	Gateway Address:	0.0.0.0				another subnet,	it must register as a
Correction (if exceeded) UPP Port: IXERCCO BBMD IP Address: 0.0.0 BBMD Reg Time: 100 (if exceeded) (if exceeded) BBMD Reg Time: 100 (if exceede) (if exceede) BBMD Reg Time: 100 (if exceede) (if exceede) BBMD Reg Time: 100 (if exceede) (if exceede) Baudrate: 19200 ▼ Protocol: Modbus Baudrate: 19200 ▼ Protocol: Modbus RTU ▼ Protocol: Modbus RTU ▼ Protocol: Modbus RTU ▼ Protocol: 1000 (100 - 3.000 msec) (200 - 30.000 msec) Corrective RD Delay: 100 COV Poll interval: 1000 (100 - 0.000 msec) Corneal Timeout (ms): Spechty Cornes Sechal State St	BACnet						
UOP Pori: OxBACO (Hexadecimal value e.g. 0xBACO) BBMD P4 address: 0.0.0 BBMD P4 address: 100 sees Virtual Network: 1100 (1 - 6534) ReadPropertyMultiple: ENABLED ~ Modius: Baudrate: 19200 ~ Protocol: Modius RTU ~ Parity: None 1 Stop-Bit ~ Command Timeout: 1000 (10 - 3.000 msec) InterScan Delay: 1000 (100 - 3.000 msec) Offine Poll Period: 15000 (2.000 - 30.000 msec) Offine Poll Period: 15000 (2.000 - 60.000 msec) OV Poll Interval: 1000 (100 - 60.000 msec) COV Poll Interval: 1000 (100 - 60.000 msec) COV Poll Interval: 1000 (100 - 60.000 msec) Apply Cancel Consecutive Red Delay file Stop Bits are appoint, its put in a device fails to respond, its put in a device		2459900	(0 - 4194302)		BBMD Reg Tim	e: Specify the time
BBMD Preddress: 0.0.0 BBMD Reg Time: 100 Ct - 65334) ReadPropertyMultiple: Enable or disable read property multiple in ReadPropertyMultiple: Enable or disable read property multiple in ReadProperty Multiple: Enable or disable read property multiple in ReadPrope	UDP Port:	0xBAC0	(Hexadecima	l value e.g. 0xBAC0)		foreign device re	gistrations.
Beaking time: 100 (1 - 6534) Yintual Network: 1100 (1 - 6534) ReadPropertyMultiple: ENABLED ▼ Modius Baudrate: (1 - 6534) Baudrate: 11200 ▼ Protocol: Modbus RTU ▼ Baudrate: 11200 ▼ Protocol: Modbus RTU ▼ Parity: None 1-Stop-Bit ▼ Command Timeout: 1000 (100 - 3,000 msec) (100 - 3,000 msec) Offine Poll Period: 15000 Consecutive RD Delay: 1000 COV Poll Interval: 1000 Apply Cancel Linkt to Site for and the wee fails to respond (100 - 3000). Default = 2,000. Event to the Master will wait for a slowe to respond (100 - 3000). Default = 2,000. CoV Poll Interval: 1000 (200 - 60,000 msec) Corrective RD Delay: 1000 Cov Poll Interval: 1000 Cov Poll Interval: 1000 Correcting RD Delay: Consective RD Delay: 000 Cov Poll Interval: 1000 Correcting RD Delay: Cov Poll Interval Consective RD Delay: 000 Cov Poll Interval For Core information and product support Offine Poll Period Consective RD Delay (ms): Set how often (2003-90.00) the Master the delay between each pol specify the delay between each pol specify the delay between each pol specify the delay between eac	BBMD IP Address:					network number	for devices
ReadPropertyMultiple: ENABLED ▼ Modbus all relevant parameters (system + each protocol) Baudrate: 19200 ▼ Protocol: Modbus RTU ▼ Protocol: Modbus RTU ▼ Command Timeout: 1000 (100 - 3.000 msec) (100 - 3.000 msec) Offine Poil Period: 1500-00 (2.000 - 3.000 msec) Offine Poil Period: 15000 COV Pol Interval: 1000 Apply Cancel Linkt to Site for more information and product support Notifies Pol Period, Hindigue and appendix and product support Notifies Pol Period, Hindigue and appendix and product support Notifies Pol Period, Hindigue and appendix and product support Notifies Pol Period, Period, Hindigue and appendix and product support Notifies Pol Period, Period, Hindigue and appendix and product support Notifies Pol Period, Period, Hindigue and appendix and product support Offine Pol Period, Period, Hindigue and appendix and product support Offine Pol Period, Period, Hindigue and appendix and product support Offine Pol Period, Period, Hindigue and appendix and product support Offine Pol Period, Period, Hindigue and appendix and product support Our and sense Colonalis, Period, Period, Period, Hindigue and appendix and product support Our staff of engineers is available to address and issues. Period, Hindigue and appendix and product support Our staff of engineers is available to address and issues of Period. Notoffication. Default = 15000ms. Our staf						485 port.	
Modbus Budrate: [y200 ~ Protocol: Modbus RTU ~ Parity: None 1-Stop-Bit ~ Command Timeout: 1000 (100 - 3.000 msec) Offine Poll Period: 15000 (2.00 - 30.000 msec) Offine Poll Period: 15000 (2.00 - 30.000 msec) Offine Poll Period: 1000 (100 - 60.000 msec) COV Poll Interval: 1000 (100 - 60.000 msec) COV Poll Interval: 1000 (100 - 60.000 msec) Apply Cancel Cancel Linkt to Site fadevice fails to respond (100-30.000). Default = 1,000ms. (100 - 60.000 msec) (100 - 60.000 msec) Command Timeout (ms): Specify NoNE 2-Stop-Bit, NoNE 1-Stop-Bit, Stop Dits are applied. COV Poll Interval: 1000 (100 - 60.000 msec) Command Timeout (ms): Specify Interval for a slave to respond (100-3000). Default = 1,000ms. Apply Cancel Cancel Colline Poll Period. Specify Interval (ms):			(1 - 65534)	-		disable read pro	
Modbus Baudrate: 19200 ▼ Baudrate: 19200 ▼ Protocot: Modbus RTU ▼ Protocot: Modbus RTU ▼ Command Timeout: 1000 ItersCan Delay: 2000 Offline Poil Period: 15000 Consecutive RD Delay: 10 Odo - 0.000 msec) (0 - 1.000 msec) COV Poil Interval: 1000 Apply Cancel Link to Site: Apply Cancel Link to Site: Cov and sends: 2.000 Boltz: Offline Poil Period (mos): Secity the delay fund: 2.0000. Cov Poil Interval: 1000 Cov Poil Interval: 1000 (Cancel Link to Site: for more information and product support Offline Poil Period (ms): Secity the delay fund: Secity the delay form: Secity the delay	ReadPropertyMultiple:	ENABLED V				BACnet.	
Moduus I19200 v Protocol: Modbus RTU v Protocol: Modbus RTU v Parity: None 1-Stop-Bit v Command Timeout: 1000 1000 (100 - 3,000 msec) Offine Poll Period: 155000 Consecutive RD Delay: 10 COV Poll Interval: 1000 More 1 (100 - 60,000 msec) COV Poll Interval: 1000 Corsecutive RD Delay: 10 OV Poll Interval: 1000 Apply Cancel Linkk to Site Coro-30.000 BaCht ere 100000000 BaCht ere Coro-30.0000 BaCht ere 1000000000000000000000000000000000000	Modbus			(system +	each protocol)		e EIA-485 bus must
Protocol: Modbus RTU v Parity: None 1-Stop-Bit v Command Timeout: 1000 (100 - 3,000 msec) InterScan Delay: 2000 (100 - 30,000 msec) Offline Poll Period: 15000 (2,000 - 1000 msec) Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (100 - 60,000 msec) Apply Cancel Command Timeout (ms): Specify the Master will wait for a slave to respond, it is put in a queue to be checked every Offline Poll Period. 1,000-80,000, Default = 7,000ms. Offline Poll Period: 1,000 (100 - 6,000 msec) Command Timeout (ms): Specify the delay between each poll cycle (100-300,000, Default = 2,000ms. Offline Poll Period. 1,000 (100 - 6,000 msec) Specify the delay between each poll cycle (100-300,000, Default = 2,000ms. Offline Poll Period. 1,000ms. Specify the delay between each poll cycle (100-300,000, Default = 2,000ms. Offline Poll Period (ms): Set how often (100-0000 msec) Specify the delay between each poll cycle (100-300,000, Default = 1,000ms. Offline Poll Period (ms): Set how often (100-0000 msec) Specify the delay between each poll cycle (100-300,000, Default = 1,000ms. Offline Poll Period (ms): Set how often (100-0000 msec) Specify the delay between each poll cycle (100-0		19200 🗸				use the same Ba	
Parity: None 1-Stop-Bit v Command Timeout: 1000 (100 - 3,000 msec) InterScan Delay: 2000 (100 - 30,000 msec) Offline Poll Period: 15000 (2,000 - 30,000 msec) Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (100 - 60,000 msec) Apply Cancel Cancel Link to Site respond, it's put in a queue to be checked every Offline Poll Period. 10,000	Protocol:	Modbus RTU 🗸		_		Baudrate: Choo	
Command Timeout: 1000 (100 - 3,000 msec) InterScan Delay: 2000 (100 - 30,000 msec) Offline Poll Period: 15000 (2,000 - 30,000 msec) Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (1000 - 60,000 msec) Apply Cancel Cancel Correspondent to the state rule of the sta	Parity:	None 1-Stop-Bit V				Protocol: Choo	
Interscall belay. 2000 (100 - 30,000 msec) Offine Poll Period: 15000 (2,000 - 30,000 msec) Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (1000 - 60,000 msec) Apply Cancel Cancel Link to Site respond, it is put in a queue to be checked every offline Poll Period (ms): Specify the delay between each poll cycle (100 - 300,000). Default = 2,000ms. Offline Poll Period Stave device is back online. Default = 15,000ms. Offline Poll Period Correscutive Read Delay (ms): Set how often (2,000 - 30,000) the Master will wait for a caccessing of a slave. Default = 15,000ms. Offline Poll Period for more information and product support Need Support? Our staff of engineers is available to naving. Please visit our website for more Paving.	Command Timeout:	1000	(100 - 3,000	msec)		Parity: Specify	
Offine Poll Period: 15000 (2,000 - 30,000 msec) Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (1000 - 60,000 msec) Apply Cancel Cancel Command Timeout (ms): Specify how long the Master will wait for a slave to respond (10:03:000). Default = 1,000ms. If a device fails to the respond (10:03:000). Default = 2,000ms. Offline Poll Period. Inter Scan Delay (ms): Specify the delay between each poll cycle (10:00-30,000) the Master othecks to see if a slave device is back online. Default = 15,000ms. Offline Poll Period (ms): Set how often (2,000-30,000) the Master othecks to see if a slave device is back online. Default = 15,000ms. Correscutive Read Delay (ms): Set how often (10:00-60000) BACnet checks: CoV and sends CoV Notification. Default = 1000ms. Cov radii de regineers is available to address any issues you may be having.	InterScan Delay:	2000	(100 - 30,000	msec)			
Consecutive RD Delay: 10 (0 - 1,000 msec) COV Poll Interval: 1000 (1000 - 60,000 msec) Apply Cancel Cancel Command Timeout (ms): Specify the delay between each poll cycle (100-300, Default = 1,000ms, It is put in a queue to be checked every Offine Poll Period. Inter Scan Delay (ms): Specify the delay between each poll cycle (100-30,000) befault = 2,000ms. Offline Poll Period. Inter Scan Delay (ms): Specify the delay between each poll cycle (100-30,000) befault = 2,000ms. Solution: Default = 1,000ms. Comsecutive Read Delay (ms): Specify the delay (0-1000) before reaccessing of a slave. Default = 1,000ms. Consecutive Read Delay (ms): Specify (ms): Specify (ms). Command Timeout (ms): Set how often (2,000-30,000) before reaccessing of a slave. Default = 1,000ms. Consecutive Read Delay (ms): Set the often (1000-60000) BACnet checks. COV Poll Interval (ms): Set how often (1000-60000) BACnet checks. COV and sends COV Notification. and product support Our staff of engineers is available to adverse any issues you may be having. Please visit our website for more	Offline Poll Period:	15000	(2,000 - 30,0	00 msec)		NONE 2-Stop-B	
COV Poil Interval: 1000 (1000 - 60,000 msec) slave to respond (100-3000). Default = 1,000ms. If a device fails to respond, it is put in a queue to be checked every Offline Poil Period. Inter Scan Delay (ms): Specify the delay between each poil cycle (100-30,000). Default = 2,000ms. Offline Poil Period (ms): Set how often (2,000-30,000) the Master checks to see if a slave torice is back online. Default = 1,000ms. Offline Poil Period (ms): Set how often (2,000-30,000) the Master checks to see if a slave torice is back online. Default = 1,000ms. Consecutive Read Delay (ms): Set how often (1000-60000) BACnet checks COV Poil Interval (ms): Set how often (1000-60000) BACnet checks COV and sends COV Notification. Default = 100ms. Cov and sends COV Notification. Default = 100ms. Need Support? Our staff of engineers is available to address any issues you may be having. Please visit our website for more Please visit our website for more	Consecutive RD Delay:	10	(0 - 1,000 ms	ec)		Command Time	
Apply Cancel respond, it is put in a queue to be checked every Offline Poll Period. Inter Scan Delay (ms): Specify the delay between each poll cycle (100-30,000). Default = 2,000ms. Offline Poll Period (ms): Set how often (2,000-30,000) the Master checks to see if a slave device is back online. Default = 15,000ms. Consecutive Read Delay (ms): Set how often (2,000-30,000) before re-accessing of a slave. Default = 15,000ms. COV Poll Interval (ms): Set how often (1000-60000) BACnet checks to see if a slave. Default = 100ms. COV and sends COV Notification. Default = 1000ms. Default = 1000ms. Default = 1000ms. Default = 1000ms. Pease visit our website for more	COV Poll Interval:	1000	(1000 - 60,00	0 msec)		slave to respond	(100-3000). Default
for more information and product support Default = 1000ms. Need Support? Our staff of engineers is available to address any issues you may be having. Please visit our website for more		Apply Cancel		Links	Cite	respond, it is pu checked every of Inter Scan Dela delay between e 30,000). Default Offline Poll Per often (2,000-30, checks to see if back online. Del Consecutive R the delay (0-100 accessing of a s 10ms. COV Poll Interv	tin a queue to be offline Poll Period. y (ms): Specify the ach poll cycle (100- = 2,000ms. iod (ms): Set how 000) the Master a slave device is ault = 15,000ms. and Delay (ms): Set lave. Default = al (ms): Set how
				for more inf	ormation	Default = 1000n Need Support? Our staff of engi address any iss	neers is available to
							website for more
©2010-2024 Contemporary Control Systems, Inc. All rights reserved.		02	010-2024 Contempora	ay control systems, Inc	An fights reserved.		

Web Page Configuration — Continued



Application Information — Using Virtual BACnet Routing

With the BACnet protocol, physical BACnet devices are assigned unique device instances. In this way, any BACnet device within the same BACnet internetwork can be uniquely identified. Accommodations must be made for non-BACnet compliant devices such as Modbus but the ability to uniquely identify each Modbus device within the BACnet internetwork can be retained thanks to the BASgatewaySX and the concept of virtual networking.

The BASgatewaySX has one Modbus serial port that can accommodate up to 200 physical Modbus serial devices. Each one of the attached devices must be configured for the same baud rate, same parity, and same serial protocol – RTU or ASCII. Each device must be assigned a unique slave ID from 1 to 246. In addition, the BASgatewaySX will also support Modbus TCP slave devices attached over Ethernet. The BASgatewaySX functions as a master to all these slave devices. Collectively, all the Modbus TCP and Modbus serial devices are assigned to a virtual BACnet network number during configuration.

Using the concept of virtual BACnet routing, each uniquely addressed Modbus slave device appears as an individual BACnet device with a unique BACnet device instance assignment. Within this BACnet device are a collection of BACnet objects that relate to Modbus data points. What is needed is a device profile for each Modbus device type which allows for the mapping of Modbus data points to BACnet object instances. Contemporary Controls maintains a library of common device profiles with the more popular profiles shipped with the product. Energy meter device profiles from Veris, Northern Design and Continental Control Systems are part of the library and more are frequently added. During commissioning, a Modbus device is "added" by selecting the appropriate device profile and assigning a unique BACnet device instance. Each device profile lists all available Modbus data points for a particular Modbus device type along with recommended BACnet object instance designations. A checkbox alongside a data point exists to indicate that this point is to be polled by the BASgatewaySX. By default, the most popular registers in each device profile are marked for polling but the user can add or delete from this list through web pages. More than 200 edited device profiles can be added each with a unique Modbus slave address and BACnet device instance. Each device profile can be the same or different depending upon the Modbus device type or the amount of points needed to be scanned. The only restriction is the 200 slot limit and the maximum total polled point count of 2000.

Shown below are three device profiles representing three Modbus devices that are to be polled for data while appearing as BACnet devices. Each device has been assigned a unique BACnet device instance. The first two devices are identical and therefore have the same device profile while the third one is a totally different device. Notice that the first two devices have different data points checked demonstrating the flexibility in selecting only those points of interest that need to be polled. When multiple identical devices, such as energy meters, are to polled — edited device profiles can be copied to further speed commissioning.

Device Name: Veris A						
Modbus Address: 40 (1 to 246)						
Modbus IP Address: 0.0.0.0						
Device Instance: 2450040						
Modbus Registers (Max 1000):						
400271 Avg Voltage L-N average of 3						
400273 Avg Current average of 3						
✓ 400275 Real Power phase A						
400277 Real Power phase B						
400279 Real Power phase C						
✓ 400281 Power Factor phase A						
400283 Power Factor phase B						
400285 Power Factor phase C						

Device Name:	Veris B				
Modbus Addre					
Modbus IP Add					
Device Instanc					
	ters (Max 1000):				
	(max 1000).				
400271 A	vg Voltage L-N average of 3	F			
🗌 400273 A	vg Current average of 3				
₩ 400275 R	leal Power phase A	٢			
✓ 400277 Real Power phase B					
✓ 400279 Real Power phase C					
✓ 400281 Power Factor phase A					
₩ 400283 F	Power Factor phase B				
₩ 400285 F	Power Factor phase C				
•		Ē			

Device Name: ND350					
Modbus Address: 10 (1 to 246)					
Modbus IP Address: 0.0.0.0					
Device Instance: 2450010					
Modbus Registers (Max 1000):					
400513 eScale Energy Register					
₽ 400515 kWh Energy Register					
☑ 400517 kVAh Energy Register					
☑ 400519 kvarh Inductive Energy Register					
✓ 400521 kvarh Capacitive Energy Register					
✓ 400523 Import kvarh Energy Register					
400525 Export kWh Energy Register					
400527 Export kvarh Energy Register	•				

Application Information — Tips on Configuration

The BASgatewaySX is shipped with a default private IP address of 192.168.92.68 /24. Once its internal web server can be reached with any standard web browser for configuration, status, and Modbus utility operations. HTML web pages allow cross-platform compatibility and browser support. There are three sections that must be addressed once the Configure Settings tab is clicked.

System

Eventually, the default IP address and subnet mask will need to be changed but if this data is ever lost, it is possible to reset the IP address to its default settings without losing any other configuration data. The installer can choose a name for the BASgatewaySX. If there is an IP router on the attached Ethernet network, provide its IP address as the Gateway Address when configuring the System settings.

BACnet

The BASgatewaySX must be assigned a unique device instance number independent from any other assignments. The UDP port is typically the default registered BACnet port 0xBAC0. Only under special circumstances this needs to be changed.

If the BASgatewaySX is to be installed on a subnetted BACnet internetwork, it will be necessary for the BASgatewaySX to register as a Foreign Device with a BACnet/IP Broadcast Management Device (BBMD) if none exists on the BASgatewaySX's subnet. If this is the case, enter the IP address of a known BBMD thereby invoking Foreign Device Registration with this BBMD. This is why the Gateway Address must be entered in the system settings. By registering as a foreign device, the BASgatewaySX will be able to receive broadcast messages originating from other subnets. A BBMD registration time must be entered so that registration is continuously renewed on a periodic basis.

The final setting is the Virtual Network address. This is the unique BACnet network number assigned to the attached Modbus devices.

Modbus

The last section in the Configure Settings screen deals only with Modbus serial devices. The first decision is to select a baud rate between 2400 and 115200 although 19200 is the default. The next is to select Modbus RTU or Modbus ASCII. Modbus RTU is much more popular and is the default. Next is the Parity setting and it is recommended to pick NONE although EVEN is the default. If no parity is selected, an extra STOP bit is added automatically so as to not change the frame length. Whatever settings are used, they MUST apply to ALL attached Modbus devices.

There are other settings that should not be touched unless for good cause. Time settings are in milliseconds. Command Timeout is the time the master waits for a response from a slave. The Inter Scan Delay is the time between each polling cycle. The Offline Poll Period is the time the master will wait before trying to contact an offline slave. The Consecutive RD Delay is the amount of time the master waits when polling the same device with consecutive reads. If the slave device is capable of responding to a block read of consecutively numbered points, the Max Consecutive RD can be limited by this number.

Mapping Modbus Points to BACnet

Modbus data is considered to be segregated into four memory blocks — coils, discrete inputs, input registers and holding registers. Discrete inputs and coils are considered to be 1-bit points while input registers and holding registers are 16-bit points. Therefore 1-bit points would be assigned either a BACnet Bl or BO object type while 16-bit points would become either an Al or AO. If the point was read-only, then it would be considered a BACnet input. All read/write points would be considered outputs. Using this convention, the following mapping rules apply when generating device profiles: Modbus Coils become BOs or BIs depending on how they are defined in the Modbus profile

Modbus Discrete Inputs become BIs

Modbus Input Registers become Als

Modbus Holding Registers become AOs or Als depend-ing on how they are defined in the Modbus profile

There is an exception to these rules. It is possible that a holding register is packed as individual status bits or control points that need to be extracted. When generating the device profile, they are broken out as individual BOs or BIs instead of one AO. Object instance numbers are then assigned sequentially for each identified Modbus point.

Application Information — Managing Modbus Devices

Once the BASgatewaySX is properly configured, Modbus device profiles can be added for each attached Modbus device. The process for adding devices is similar for Modbus Serial or Modbus TCP devices.

Adding a Device

By clicking on the Mapping Configuration tab you will be presented with a Configured Devices box showing all Modbus devices that are currently being assessed by the BASgatewaySX. Clicking on any of the devices listed will show you a Device Information box showing the device profile of that particular device. The device profile lists all available Modbus points with each entry having a box along side. A checked box means that the associated point is being included in the BASgatewaySX's scan list.

When viewing the Configured Devices box, a Modbus device can be added by clicking the Add button. From the dropdown Device Profile menu select the appropriate device profile for the device to be added. You will notice the selected profile with pre-checked boxes was added. You can add or delete those points of interest at any time before submitting the device to the scan list. Next assign the Modbus slave address from 1-246. If the device is Modbus serial device, leave the Modbus IP Address at its default 0.0.0.0 setting. If the device is a Modbus TCP device, enter its IP address as well as its slave address. If the Modbus TCP device is on a different subnet to that of the BASgatewaySX, communications is possible if IP routers are installed on the respective subnets.

A unique BACnet device instance number will need to be assigned to each connected Modbus device and the BASgatewaySX has a scheme to make assignments easier. Notice that the Device Instance Auto box is checked meaning that the BASgatewaySX will attempt to automatically assign unique BACnet device instances to each BASgatewaySX being installed. The 7-digit format uses 245 as the leading number which is Contemporary Controls BACnet vendor ID. The following digit is determined by the Region Number which can range from 0 to 9. The final digits are the Modbus slave address. If there is only one BASgatewaySX within the BACnet internetwork, then there is no need to increment the Region Number from its default value of zero. If more than one BASgatewaySX is being used in the same system, increment the Region Number for each added BASgatewaySX up to 9 to be sure no duplicate BACnet device instances are generated. Above 10 BASgatewaySXs it will be necessary to enter the BACnet device instance manually. Uncheck the Device Instance Auto box and enter a unique number from 0 to 4194302. To complete configuration, you can enter a name for the device you added on the top line. Once all entries are made press Submit and then Back to return to the Configured Devices box. Once there, refresh the box and you will see your new device.

Modifying, Copying and Deleting Devices

From the Configured Devices box you have the capability to modify settings in a device, copy a device if multiple instances of the same device are to be used — and finally, you can delete a device.

Mapping Status

By clicking on Mapping Status you can determine the number of Modbus devices that are online by observing the Unit Status box. To view a particular device, go to the Device Instance drop-down box and select the device of interest. Its Modbus address will automatically appear to the right of the device instance. Modbus TCP devices will appear as a combination of IP address and Modbus slave address. Using the Object Instance drop-down box you can scroll through all the objects that are being polled within that device. The first reference is the actual BACnet object instance which is followed by the object instance type (AI, AO, BI or BO). The last reference is the Modbus point. After selecting one of the objects, an object property can be selected through the Object Property drop-down. The more interesting property would be the Present Value of the object. The present value of all objects can be read by clicking on the Read button but not all objects can be written by supplying a value and clicking on the Write button. If the object property cannot be written, the Write button will be greyed out.

Upload Profile

Standard device profiles come with the device but new ones are continuously being developed. Newly developed profiles will be posted on the BASgatewaySX product support page which can be found on <u>https://</u><u>www.ccontrols.com</u>. In addition, Contemporary Controls will develop or modify an existing device profile based upon a customer's request. Wherever the source of the new or modified device profile, it must first be loaded onto the customer's computer and then it can be uploaded to the BASgatewaySX following instructions under the Upload Profile tab.

Application #1 — **Two Virtual Networks**

The most common application is adding one or more Modbus serial networks to a BACnet system. Each Modbus serial network must be configured for the same Modbus serial protocol (RTU or ASCII), the same data rate (2400–115200 baud), and the same parity (ODD, EVEN or NONE). Make sure any wiring issues with 2-wire and 3-wire devices are addressed. With the system shown as below, two virtual BACnet networks must be assigned — network 1 and network 2 — which are separate from the real BACnet network numbered as 3 in this example. If you are using the Device Instance Auto feature to automatically assign device instances, you must select a different Region Number for the two BASgatewaySXs to ensure that no duplicate device instances are generated.



Application # 2 — Mixing Modbus TCP and Modbus Serial

The BASgatewaySX can handle both Modbus TCP devices and Modbus RTU devices simultaneously using just one BASgatewaySX as long as the 200 device/2000 polled point limit is maintained. In this application the Modbus TCP connection is called a "one-armed gateway" because both Modbus TCP and BACnet/IP messages transfer through the same Ethernet port. Configuration is similar to that of a Modbus serial device. However, this time the IP address of the Modbus TCP device must be entered as well as a Modbus slave address. A potential conflict could exist when using the Device Instance Auto feature and an attached Modbus TCP device and an attached Modbus Serial device happen to use the same slave address. If a conflict is reported by the BASgatewaySX, simply set the device instance manually — or select a different Region Number.



Application # 3 — Modbus Serial to Modbus TCP Routing

Inherently, the BASgatewaySX will function as a Modbus serial to Modbus TCP router. In this mode no mapping configuration is needed since BACnet is not involved. Modbus TCP devices can function as clients, servers or client/servers. When a Modbus TCP server device is configured, it must be assigned a slave address as well as an IP address. When a Modbus TCP client accesses a Modbus TCP server, communications occurs

over Ethernet with no involvement with the BASgatewaySX. However, if a Modbus TCP client communicates with a Modbus serial device, the message is routed through the BASgatewaySX to its serial bus. For this application, no configuration is required other than the System and Modbus settings under the Configure Settings tab.



Application #4 — **Subnetted IP Network**

NTROLS

With IP networks, it is possible that BACnet client devices, the BASgatewaySX and Modbus TCP devices may all reside on different subnets interconnected through IP routers. The BASgatewaySX will still operate under these conditions. Shown below are a BACnet client with BBMD capability and Modbus TCP servers on subnet 1 with the BASgatewaySX and other Modbus TCP servers on subnet 2. Attached to the BASgatewaySX serial port are Modbus serial devices. Between the two subnets is an IP

router. Enable foreign device registration in the BASgatewaySX by setting its BBMD IP Address field to the IP address of the BACnet client. In the BASgatewaySX's System setup, set the Gateway Address to the IP address of the IP router. Modbus TCP and Modbus serial devices are entered as normal — allowing the BACnet client (or other BACnet clients) to discover all Modbus devices without issue.



BACnet Protocol Implementation Conformance (PIC) Statement

BASgatewaySX Modbus to BACnet [®] Con			8	
BACnet Prot	ocol Im	plementation C	onformance	Statement (Annex A)
Date: Vendor Name: Product Name:	BASgatewa	rary Controls aySX		
Product Model Number: Applications Software Version: 7 Product Description: Gateway b		Firmware Revision: 2.0).9 BACnet F	Protocol Revision: 14
BACnet Standardized Device Pro	ion (B-OWS) or Workstatio B-OD))		
List all BACnet Interoperability B DS-RP-B Data Sharing — Re DS-WP-B Data Sharing — Wr DS-RPM-B Data Sharing — R DS-COV-B Data Sharing — C	adProperty – iteProperty – eadProperty	B DM-DDB B DM-DOB Multiple – B DM-DCC	-B Device Manager -B Device Manager -B Device Manager	nent — Dynamic Device Binding – B ment — Dynamic Object Binding – B ment — Device Communication Control – B ent — Time Synchronization – B
Segmentation Capability:		Window Size: Window Size:		
Standard Object Types Supporte				
Object Type Supp Analog Input	orted	Can Be Created No	Dynamically	Can Be Deleted Dynamically No
Analog Output		No		No
Binary Input		No		No
				NI-
Binary Output		No		No
	ported.	No No		No
Binary Output Device	eign Device use 7) ET (Clause 8 IET (Clause 8	No No 8), baud rate(s):	Point-To-Poi	No (Clause 9), baud rate(s): nt, EIA 232 (Clause 10), baud rate(s): nt, modem, (Clause 10), baud rate(s): ause 11), medium:
Binary Output Device No optional properties are sup Data Link Layer Options: ⊠ BACnet IP, (Annex J) ⊠ BACnet IP, (Annex J), Ford □ ISO 8802-3, Ethernet (Clauding) □ ATA 878.1, 2.5 Mb. ARCN □ ATA 878.1, EIA-485 ARCN □ MS/TP master (Clause 9), Device Address Binding:	eign Device use 7) ET (Clause 8 IET (Clause 8 baud rate(s): ted? (This is	No 8) 8), baud rate(s):	 Point-To-Poi Point-To-Poi LonTalk, (Cla BACnet/Zigb Other: 	No (Clause 9), baud rate(s): nt, EIA 232 (Clause 10), baud rate(s): nt, modem, (Clause 10), baud rate(s): ause 11), medium:
Binary Output Device No optional properties are sup Data Link Layer Options: ⊠ BACnet IP, (Annex J) ⊠ BACnet IP, (Annex J), Fort □ ISO 8802-3, Ethernet (Clau □ ATA 878.1, 2.5 Mb. ARCN □ ATA 878.1, EIA-485 ARCN □ MS/TP master (Clause 9), Device Address Binding: Is static device binding support	eign Device use 7) ET (Clause 8 IET (Clause 8 baud rate(s): rted? (This is lo routing conf ng Router ov agement Dev registrations	No 8), baud rate(s): currently necessary for igurations, e.g., ARCNE er IP rice (BBMD) by Foreign Devices?	Point-To-Poi Point-To-Poi LonTalk, (Cla BACnet/Zigb Other: two-way communic T-Ethernet, Ethernet	No (Clause 9), baud rate(s): nt, EIA 232 (Clause 10), baud rate(s): nt, modem, (Clause 10), baud rate(s): ause 11), medium: ee (Annex O) ation with MS/TP slaves and certain other
Binary Output Device No optional properties are sup Data Link Layer Options: ⊠ BACnet IP, (Annex J) ⊠ BACnet IP, (Annex J) □ ISO 8802-3, Ethernet (Clau □ ATA 878.1, 2.5 Mb. ARCN □ MS/TP master (Clause 9), Device Address Binding: Is static device binding suppor devices.) Yes Networking Options: □ Router, Clause 6 — List al □ Annex H, BACnet Tunnellii □ BACnet/IP Broadcast Man □ Does the BBMD support	eign Device Ise 7) ET (Clause 8 IET (Clause 4 baud rate(s): rted? (This is lo routing conf ng Router ov agement Dev registrations network addi character se □ IBM™/	No No No No No No No No No No	Point-To-Poi Point-To-Poi LonTalk, (Cla BACnet/Zigb Other: two-way communic T-Ethernet, Ethernet Yes No es No	No (Clause 9), baud rate(s): nt, EIA 232 (Clause 10), baud rate(s): nt, modem, (Clause 10), baud rate(s): ause 11), medium: ee (Annex O) ation with MS/TP slaves and certain other t-MS/TP, etc.
Binary Output Device No optional properties are sup Data Link Layer Options: Analysis BACnet IP, (Annex J) BACnet IP, (Annex J) BACnet IP, (Annex J), Ford ISO 8802-3, Ethernet (Clau ATA 878.1, 2.5 Mb. ARCN ATA 878.1, 2.5 Mb. ARCN MS/TP master (Clause 9), Device Address Binding: Is static device binding suppor devices.) Yes Yes N Networking Options: Router, Clause 6 — List al Annex H, BACnet Tunnellii BACnet/IP Broadcast Man Does the BBMD support Does the BBMD support Indicating support for multiple ISO 10646 (UTF-8) ISO 10646 (UCS-2)	ign Device use 7) ET (Clause 8 IET (Clause 8 baud rate(s): ted? (This is lo routing conf ng Router ov agement Dev registrations network add character se ☐ IBM™/ ☐ ISO 1(No 8), baud rate(s): currently necessary for igurations, e.g., ARCNE er IP rice (BBMD) by Foreign Devices? ress translation? Y ts does not imply that the Microsoft™ DBCS 0646 (UCS-4)	Point-To-Poi Point-To-Poi LonTalk, (Cla BACnet/Zigb Other: two-way communic T-Ethernet, Ethernet Yes No es No ey can all be suppo ISO 88 IJS X 0	No (Clause 9), baud rate(s): nt, EIA 232 (Clause 10), baud rate(s): nt, modem, (Clause 10), baud rate(s): ause 11), medium: ee (Annex O) ation with MS/TP slaves and certain other t-MS/TP, etc.

Wiring Diagrams

Since the product incorporates a half-wave rectifier circuit, it can share the same 24 VAC power with other half-wave rectified devices. It can also be powered from a 24 VDC source. A redundant power connection exists (HIB) for back-up power schemes.

The product incorporates a 3-wire optically-isolated EIA-485 interface for the serial connection, allowing better circuit protection and noise immunity. To connect to other 3-wire devices simply make a one-to-one connection to the other devices. But when connecting to 2-wire non-isolated

devices, the signal common (SC) on the product must share the reference used by the 2-wire devices. This is accomplished by tying the SC pin to COM on the product and by grounding the low-side of each power supply on all connected devices. In this way all EIA-485 transceivers share the same earth reference. Notice that the SC pin is signal common and not a shield pin. For shield connections, use the SH pin. Far-end external termination is required as shown. Near-end bias and termination are internally supplied within the product.



3-wire Modbus Network

2-wire Modbus Network



Data Sheet – BASgatewaySX

Connector Pin Assignments

Ethernet

TD+

TD-

RD+

N/C

N/C

RD-

N/C

N/C

34567

Function

Pin

1

2

3

4

5

6

7

8

EIA-485



Power

Pin	Function
HIB	Redundant Power
HI	DC+ or AC High
СОМ	0V or AC Low
\rightarrow	Chassis





Panel Mount

100 mm



Specifications

Power Requirements Input Power	(Class 2 Circuits Only 24 VAC ±10% 3 VA 4	y) 7–63 Hz or 24 VDC ±1	10% 2 W		
Operating Temperature	–40°C to +75°C				
Storage Temperature	–40°C to 85°C				
Relative Humidity	10–95%, non-condensing				
Protection	IP30				
Communication Compliance Protocols supported Data rate Physical layer Cable length (max) Port connector	Ethernet IEEE 802.3 Modbus TCP BACnet/IP 10 Mbps, 100 Mbps 10BASE-T, 100BASE-TX 100 m Shielded RJ-45		EIA-485 Modbus V1.02 RTU Master ASCII Master 2.4, 4.8 9.6, 19.2, 38.4, 57.6, 115.2 kbps EIA-485, 3-wire isolated 1200 m (or 1000 m if using 115.2 kbps) 5-pin removable terminal		
LEDs Regulatory Compliance	<i>L (Link)</i> Green = Link Flash = activity CE Mark; CFR 47, Par UL 61010; C22.2 No.		Tx Green = activity	Rx Green = activity RoHS US	

Ordering Information

Model BASGSX-M1 BASGSX-M1/P RoHS

Description

BASgatewaySX Modbus to BACnet Gateway DIN rail Mount with SSL BASgatewaySX Modbus to BACnet Gateway Panel Mount with SSL

United States

Contemporary Control Systems, Inc.

Tel: +1 630 963 7070 Fax:+1 630 963 0109

info@ccontrols.com

China Contemporary Controls

(Suzhou) Co. Ltd Tel: +86 512 68095866

Fax: +86 512 68093760

info@ccontrols.com.cn

United Kingdom Contemporary Controls Ltd

Tel: +44 (0)24 7641 3786 Fax:+44 (0)24 7641 3923

ccl.info@ccontrols.com

Germany

Contemporary Controls GmbH

Tel: +49 341 520359 0 Fax: +49 341 520359 16

ccg.info@ccontrols.com

www.ccontrols.com