Sedona Project Backup and Restore Utility



Using the Sedona Project Backup and Restore Utility

Introduction

The Sedona Project Backup and Restore utility program (BASbackup) provides a convenient way of saving and restoring a BAScontrol project to a desktop or laptop computer. With the BAScontrol, a project consists of the following files:

- · Sedona Framework binary application file (app.sab.target)
- Sedona Framework source application file (app.sax)
- BAScontrol configuration file (bas_cfg.xml)
- BAScontrol Scode file (kits.scode)
- BAScontrol web component file (webc.xml)

These files are sufficient to completely backup a BAScontrol project without the need of a Workbench tool. Although Sedona files can be backed up and restored using the Workbench tool using the Get and Put commands, the BAScontrol configuration and web component configurations are ignored. Therefore the Sedona Project Backup and Restore utility is the best and simplest way to store BAScontrol projects. The BASbackup program is applicable to BAScontrol20 firmware 3.0.28 and later or BAScontrol22 firmware 3.1.0 and later.

Installation

BASbackup is a Java program (version 7_51 or later) and is intended to run on a Linux, Windows[©] 7 or later computer. The latest version can be downloaded as a zip file (BASbackup Utility version 1.0.x) from our website at:

http://www.ccontrols.com/support/bascontrol20.htm

Place the downloaded file anywhere on your computer. — we suggest your desktop for unzipping. Extract the files from the zip file and choose a location that would be convenient for you. We suggest the root directory of your main drive (for example C:). Make a folder called BASbackup during the extracting process and extract the contents of the zip file into this folder. You will see the following files:





BAScontrol20



The Java utility is BASbackup and for convenience a Component Bundle for the latest version of the BAScontrol is provided. The Component Bundle provides kit information on the component types that can be used with the BAScontrol. You can always download later versions of BAScontrol bundles if necessary from the same web site page. Simply replace the current bundle with the latest if a later BAScontrol version is to be supported. Later bundle versions include support for both current and previous versions of the BAScontrol so having the latest poses no harm. Leave the Component Bundle zipped.

Double-click the BASbackup icon and the program will open up as shown below with a default IP address of a factory-set BAScontrol. A configuration file for the program along with a backups folder will be created in the same BASbackup folder. The backups folder will be the location of your backup files. The **Unit Status** will indicate **UNKNOWN** until a connection is made to a BAScontrol.

BAScontrol IP Address	Unit Status	
192.168.92.68	UNKNOWN	
Backup/Recovery File		
backup.zip		Choose File
		Restore
Backup		

Figure 1 — The Default BASbackup Screen

Backing up a Sedona Project

Enter the correct BAScontrol IP Address of the BAScontrol that is to be backed up if it has been changed from its default address. This utility program will attempt to communicate with a device at the address entered. Make sure your computer is on the same subnet as the target controller. The target controller must be powered with Sedona enabled and accessible. The utility provides you a default backup file location. If you want something different you can edit the location on the screen. It is not necessary that the file exists. The utility will create the file you named and append the zip extension as well. If you have a previous file which you want to overwrite, you can use the *Choose File* button to find it. The utility will first look for it in the backups folder but you can use the navigation buttons if the file location is somewhere else on your computer. Once you are ready, click *Backup*.

🔬 Authentication	x
User Name	
admin	
Password	
••••	
Sedona wire sheet user name and password authentication is needed	
before backup or restore.	
OK Cance	el

Figure 2 — The Authentication Screen

With the correct BAScontrol IP Address entered, click the *Backup* button and a credentials window will appear from the targeted controller. Enter the *User Name* and *Password* of the Sedona Framework application in the BAScontrol20. The default credentials are *admin/admin*. The *User Name* and *Password* of the web pages are unnecessary and cannot be used.

BAScontrol IP Address	Unit Status	
10.0.61	ONLINE	
Backup/Recovery File		
RTU_1.zip		Choose File
Backup]	Restore

Figure 3 — Specifying a New IP Address and Backup File Name

In our example and as shown in Figure 3, we changed the IP address and renamed the backup file. If you are successful no error messages will appear. Once the red progress messages cease on the main page you can look at the contents of your backup zip file by double-clicking it in the backups folder. You should see the five files that were identified earlier.

Computer 🕨 Windo	ows (C:) 🕨 BA	Sbackup 🕨 backups	RTU_1
▼ Extract all files			
Name	Туре	Compressed size	
🔳 app	SAX File		7 KB
app.sab.target	TARGET File		4 KB
bas_cfg	XML File		3 KB
kits.scode	SCODE File		77 KB
webc	XML File		1 KB

Figure 4 — Content of the RTU_1 Backup ZIP File

Restoring a Sedona Project

Restoring a Sedona Project is just as easy. Before you begin the restore process, set the IP address on the main page to the location of the controller to be restored. The controller must be powered up and accessible. You will need to select the appropriate backup file by first clicking *Choose File* on the main page and selecting the file.

🍰 Open			×
Look <u>i</u> n:	backups	•	
Pot_test.zi			
File <u>N</u> ame:	RTU_1.zip		
Files of <u>Type</u> :	Zip Files		-
		Ope	n Cancel

Figure 5 — Choosing a Restore ZIP File

In this example we are going to restore RTU_1.zip to controller 10.0.0.61. Once you have the correct backup file and IP address as shown in Figure 6, click the *Restore* button on the main page to get the screen of Figure 7.

BAScontrol IP Address 10.0.0.61	Unit Status ONLINE	
Backup/Recovery File		
RTU_1.zip		Choose File
Backup		Restore

Figure 6 — Restoring to 10.0.0.61

IP Address		Check the box to allow chang	
10.0.0.61	Change Recovery Data	configuration data sent to the	BAScontrol.
Nefmask		Configuration values in the te values in the Main Configurat	
255.255.255.0		Restore operation is performe	
Gateway 10.0.0.1		If changes are made, you will new Backup/Recovery file. If y overwrite the current file, the	ou chose to
BACnet Device Instance		Gateway, Device Instance, and	d Device Name will
2749061		be changed in the Main Confi the Backup/Recovery zip file.	guration file within
BACnet Device Name RTU_1			
New Backup/Recovery File			
RTU_1.zip			Choose File
Restore Options			
Wire Sheet Kits Main Configuration			
Web Component Configura	tion		
Restore			Cancel

Figure 7 — Restore Setup Screen

First notice the location of the Backup/Recovery file. Is this the file you want restored? Second, look at the top of the screen and you will see the following parameters:

- IP Address
- Netmask
- Gateway
- BACnet Device Instance
- BACnet Device Name

These five parameters will be loaded into the controller being restored. Are these five parameters that come from the saved zip file what you want? Is the IP address of the target controller the same as shown on this page? If so, study the *Restore Options*.



There are some options available before restoring a controller. Under the *Restore Options* there are four boxes:

- Wire Sheet
- Main Configuration
- Web Component Configuration
- Kits

By un-checking boxes you can control what individual files are being restored. Consider this an advanced feature because under normal conditions you want to make sure that all files you saved in the project backup file are going to be reflected in the restored controller.

Once you are convinced the settings are correct, click the *Restore* button.

Once the Restore operation is completed, evidenced by the completion of progress messages, the application program in the target controller continues to run the old program. In order to run the newly restored program, a controller Restart is required. You will be prompted for an immediate restart. You can do it now or later.

If you want to restart the controller later, this can be accomplished by clicking the *Restart BAScontrol* button on the BASbackup main page or by restarting from the controller's web page. Regardless of what method is used, care should be exercised when restarting the program on an active controller. The controller and application should be in sight of the systems integrator initiating the restart to confirm a safely functioning restart of the application.

Cloning a Sedona Project

It is also possible to direct a saved program to a different controller that needs to run the identical saved program. However, the IP address, netmask and gateway address stored in the saved backup file need to reflect the target controller otherwise there will be an IP conflict. In addition, the BACnet Device Instance and BACnet Device Name must be unique so it must be changed from what is in the stored in the saved file. On the BASbackup main page (Figure 8), set the IP address of the target controller and choose the backup file that is to be used for cloning. In this example we are going to use RTU_1.zip for cloning to the 10.0.0.62 controller. Once the information is correct click *Restore* to get you to Figure 9.

Sedona Project Backup and Restore	e 1.0.12	
BAScontrol IP Address	Unit Status	
10.0.62	ONLINE	
Backup/Recovery File		
RTU_1.zip		Choose File
Backup		Restore
Get SAX Data	Restart BAScontrol	Close

Figure 8 — Specifying the IP Address and the Backup ZIP File for Cloning



Figure 9 — Restore Setup Screen for Cloning

On the Restore Setup page, check the box entitled *Change Recovery Data*. Now you are able to change the settings of the five parameters to suit the target controller. Enter the *IP address* of the target controller. The *Netmask* and *Gateway* probably do not need to change. The *BACnet Device Instance* should be changed to something unique as should the *BACnet Device Name*.

Since the target controller is for RTU_2 we will use this name while changing the *BACnet Device Instance*. It is also a good idea to save the cloned controller settings to a new zip folder for easy recovery. In this way we will have a unique backup file for every controller on the job. In our example, the target controller is RTU_2 so that is what we are going to enter for the new backup program we are going to generate. Enter the new backup file name. Since we want all types of files saved we will leave the four Restore Option boxes checked.

This is important to remember. The IP address on the Restore Setup screen will become the controller's IP address once the controller is restarted. So it is possible to send the Restore Setup data to a controller with a different IP address than the one indicated on the Restore Setup screen. The file is always sent to the IP address indicated on the BASbackup main page. However, once the controller is restarted it will assume the IP address indicated on the Restore Setup screen. This could be very handy when you have several BAScontrols at factory-default IP addresses that are to be commissioned to specific IP addresses in the field using a common program. Just make sure you provide unique BACnet references and IP addresses for each controller. If you have different IP addresses on the Restore Setup screen and the BASbackup main page, you will receive an Alert message asking if you want to proceed (Figure 11).

Click Restore.

Once the Restore operation is completed, the application program in the target controller continues to run the old program. In order to run the newly restored program, a controller Restart is required. You will be prompted for an immediate restart. You can do it now or later. If you want to restart the controller later, this can be accomplished by clicking the *Restart BAScontrol* button on the BASbackup main page or restarting from the controller's web page. Regardless of what method is used, care should be exercised when restarting the program on an active controller. The controller and application should be in sight of the systems integrator initiating the restart to confirm a safely functioning restart of the application.

When you are finished, you will have cloned a controller in the field but configured it appropriately in terms of IP address and BACnet settings. You also have created a new backup file for project storage.

Computer 🕨 Windo	ows (C:) 🕨 BASbao	ckup ► backups ► RTU_2
▼ Extract all files		
Name	Туре	Compressed size
🔳 app	SAX File	7 KB
app.sab.target	TARGET File	e 4 KB
bas_cfg	XML File	3 KB
kits.scode	SCODE File	77 KB
📄 webc	XML File	1 KB

Figure 10 — Content of the RTU_2 Backup ZIP File

Alert	
?	Restoring data from a different IP address; proceed?
	<u>Y</u> es <u>N</u> o

Figure 11 — Alert message when IP addresses differ in a restore operation.



Getting SAX Data

There is a convenient feature on the BASbackup utility. By the utility recreating the Sax file from the Sab file, we can learn the amount of memory being used in the saved application or even from an active controller in the field with an unknown file. Click on the *Get SAX Data* button and you will see the following window:

	Use SAX file from Zip (RTU_1.zip)	Use SAX file on BAScontrol (10.0.0.61)	
Device Name		Get Data	
App Name			
Number of Components			
Number of Links			
RAM Used			

Figure 12 — SAX File Statistics Screen

The default selection gives you the data from the saved zip file indicated. If you use this option, make sure the saved location is what you want otherwise browse from the main page for the correct location. Click on Get Data to retrieve the data.

	Use SAX file from Zip (RTU_1.zip)	Use SAX file on B/ (10.	AScontrol 0.0.61)
Device Name	RTU_1		Get Data
App Name	RTU 1H1C		
Number of Components	165		
Number of Links	188		
RAM Used	14312		

Figure 13 — SAX File Statistics Screen

If instead you check the box that provides the Sax file from a controller in the field, make sure the IP address indicated is the desired controller otherwise change the IP address on the main page.

	Use SAX file from Zip (RTU_1.zip)	✓ Use SAX file on BAScontrol (10.0.0.61)
Device Name	RTU_1	Get Data
App Name	RTU 1H1C	
Number of Components	165	
Number of Links	188	
RAM Used	14312	

Figure 14 — SAX File Statistics Screen

CONTEMPORARY

ONTROL

United States Contemporary Control Systems, Inc. 2431 Curtiss Street Downers Grove, IL 60515 USA	China Contemporary Controls (Suzhou) Co. Ltd 11 Huoju Road Science & Technology Industrial Park New District, Suzhou PR China 215009	United Kingdom Contemporary Controls Ltd 14 Bow Court Fletchworth Gate Coventry CV5 6SP United Kingdom	Germany Contemporary Controls GmbH Fuggerstraße 1 B 04158 Leipzig Germany
Tel: +1 630 963 7070	Tel: +86 512 68095866	Tel: +44 (0)24 7641 3786	Tel: +49 341 520359 0
Fax:+1 630 963 0109	Fax: +86 512 68093760	Fax:+44 (0)24 7641 3923	Fax: +49 341 520359 16
info@ccontrols.com	info@ccontrols.com.cn	ccl.info@ccontrols.com	ccg.info@ccontrols.com
www.ccontrols.com	www.ccontrols.asia	www.ccontrols.eu	www.ccontrols.eu